



268 West Beaver Street
Suite 112
Hellam, PA 17406
717-840-0264 phone
717-755-4039 fax

Changing the Date and Time on a Vodavi Talkpath

1. Access your voicemail box
2. After you enter your password, Press "7" (hidden administrator key)
3. Enter the System Admin password 2275
4. Press 8 – for System Administration
5. Press 4 – to change system date & time
6. The system will then play the current date and time.
7. The system will prompt you to enter the following:
 - a. Enter the 2 digit month (01-12)
 - b. Enter the 2 digit day (01-31)
 - c. Enter the 4 digit year
 - d. Enter the 2 digit hour (24 hour mode- 00-23)
 - e. Enter the 2 digit minute (01-59)
8. The system will then replay the time that you entered.
 - a. Press "#" to confirm
 - b. Press "*" to cancel
9. The system will then reboot and will restart in 2 minutes.
10. Hang up when finished